

# Maintenance Technical Instruction

Customer		Document No.	
Product Name	PF-801	Issued Date	2007/8/7
		Part Number	
Defective Description		Add schedule on/off function	
Maintenance Procedure		Update Firmware	
Spare Parts		No need	
Tooling Requirement		SD Card	

## Maintenance Procedure:

**Notes: Please use SD card to upgrade firmware.**


Step 1: Store the firmware file into SD card

When receiving the firmware compressed file. Please decompress it and copy it to your SD card. The firmware has to be on the first layer. Don't put it under any folder.



Step 2: Turn On the Photoframe





Step 3: Plug in SD Card (with firmware)



Step 4: Firmware updating



**Firmware update will process automatically**



**Firmware update completed**

Step 5: Take off the SD card and turn off photoframe.



Remember to delete the firmware from your SD card before you insert to the device again.