


ENGLISH

System Requirements:

Compatible with Windows 7/ Vista / XP /2000
Available USB Port

USB port









Hardware Installation:

Plug the USB keyboard into your PC USB port.









Keyboard hotkeys and Fn-Keys definition:



Fn Function keys:

 + 	Turn the system into sleep mode
 + 	Search for a file or folder.
 + 	Open mail folder.

ENGLISH

	Open browser in Netscape or IE.
	Remove the sound.
	Turn down the volume.
	Turn down the volume.
	Go back to the previous track
	Stop play of audio or video CD.
	Play and pause the audio or video sources.
	Skip to the next track